

COFA Series 6, 8, and 12 Tools

STEP 1:

Insert the long end of the assembly pin into the roll pin.

STEP 2:

Drive the roll pin out of the tool body. Keep the roll pin to reuse it.

STEP 3:

Remove the assembly pin and then remove the blade.

STEP 4:

Place new blade into the tool with the notch on the end of the spring.

STEP 5:

Place the long end of the assembly pin through the holes to align the blade in the tool.

STEP 6:

Place the roll pin on the end of the assembly pin and hammer it into the tool. Use the assembly pin to maintain the proper alignment.

STEP 7:

Place the short end of the assembly pin into the roll pin and drive the assembly pin so it seats against the counterbore.

