

STEP 1:

Remove the Clamping Screw with with a #8 Torx Wrench.

STEP 2:

Pull the Housing from the Tool Body and remove the Blades from the Housing.

STEP 3:

Place new blades in the blade window of the housing with numbers out and slots down. Blades should be flush with the housing.

STEP 4:

Push the Housing down onto the Tool Body and make sure the hole with screw hole on the Tool Body.

STEP 5:

Rotate the Housing 45° to engage the blades (you will hear a clicking sound and blades will extend and retract once engaged). Rotate the Housing back 45° to align the screw holes.

STEP 6:

Insert the Clamping Screw and Tighten down.

